

WEIGHING HAND PALLET TRUCK RAVAS-1100

ERSATZTEILLISTE
LISTE DE PIÈCES DÉTACHÉES
LISTA RICAMBI

SPARE PARTS LIST
ONDERDELENLIJST

30.08.10



Nr.* No.* No.*	Art. Nr. No. d'art. Num. art.	Umschreibung Description Descrizione	Description Omschrijving	Anz. No. Qtà.
1	899193001.31	FS-H-RAL3000 Gabelschuhe fourches set sovrarforche	set fork shoes set vorkschoenen	1
2	895200760	PT-H-RAL3000 Fahrgestell châssis Telaio	chassis chassis	1
3	891112256 891112255	LC-1000 LC-1000-ECO Lastzelle capteur cella di carico	load cell krachtopnemer	4
4	899172200	MP-MP-6 Montageplatte Lastzelle 6 mm plaque de montage capteur 6 mm spessore fissaggio 6mm cella di carico	mounting plate load cell 6 mm montageplaat krachtopnemer 6 mm	4
5	894141903	MP-BOLT-M12-35-CYL Lastzelle Montagebolzen (inbus M12 x 35) vis fixation capteur (à six pans creux M12 X 35) vite di fissaggio cella di carico (testa a brugola, M12 x 35)	load cell mounting bolt (inbus M12 x 35) krachtopnemer montagebout (inbus M12 x 35)	8
6	894141922	MP-BOLT-M12-60-COUNTERSUNK Gabelschuhe Montagebolzen (inbus M12 x 60, Senkkopf) vis fixation fourche (à six pans creux M12 X 60, à tête fraisée) vite di fissaggio sovrarforca (svasata, testa a brugola, M12 x 60)	fork shoe mounting bolt (inbus M12 x 60 sunken) vorkschoen montagebout (inbus M12 x 60 verzonken)	4
7	894142331	MP-NUT-M12-LOCKNUT Gabelschuhe Montagemoerter selbstsichernd (inbus M12) écrou fixation fourche (à six pans creux M12) dado frenato di fissaggio sovrarforca (esagonale M12)	fork shoe mounting nut self tightening (inbus M12) vorkschoen montagemoer zelfborgend (inbus M12)	4
8	895201705	PTP-H-HAN-RAL7021 Deichsel poignée timone	handle disselboom	1
9	895200780.1	PTP-H-PUMP-RIBS Pumpe pompe pompa	pump pomphuis	1
10	895201799	PTP-H-REP Dichtungssatz kit réparation (joints) set guarnizioni	pump repair set pomphuis reparatieset	1
11	895201701	PTP-H-WH-ST-PU Lenkrad (Polyurethaan) roues de direction (polyuréthane) ruota di guida (poliuretano)	steering wheel (polyurethane) stuurwiel (polyurethaan)	2
12	895201702	PTP-H-WH-ST-PU Lastrad (Polyurethan Tandem) roues de charge (polyuréthane tandem) ruota di carico (doppie in poliuretano)	loading wheel (Polyurethane tandem) lastwiel (Polyurethaan tandem)	2
13	894141664	MP-BOLT-M8-20-CYL Indikatorhalter Montagebolzen (inbus M8 x 20) vis fixation support indicateur (à six pans creux M8 X 20) vite di fissaggio supporto indicatore (testa a brugola, M8 x 20)	indicator support mounting bolt (inbus M8 x 20) indicator steun montagebout (inbus M8 x 20)	3
14	899193024.3 893207015	HOP-PT-FO-SYN HOP-PT-FO-SYN Indikatorhalter support indicateur supporto indicatore	indicator support indicator steun	1
15	894141662	MP-BOLT-M8-16-CYL Gehäuse Montageschraube (Inbus M8 x 16) vis de montage boîtier (à six pans creux M8 X 16) vite di fissaggio custodia (testa a brugola, M8 x 16)	enclosure mounting bolt (inbus M8 x 16) behuizing montagebout (inbus M8 x 16)	2
30	892203000.1	FR-21-RAV-HO Tastatur clavier tactile tastiera	touch panel toetspaneel	1
31	894141663	MP-BOLT-M6-40-CYL Gehäuse Schraube (Inbus M6 x 40) vis boîtier (à six pans creux M6 X 40) vite custodia (testa a brugola, M6 x 40)	enclosure bolt (inbus M6 x 40) behuizing bout (inbus M6 x 40)	2
32	893141171.1	HOP-RAV-RAL3000-UPPER Oberer Teil Gehäuse (roter Teil) partie supérieure du boîtier (partie rouge) parte superiore custodia (in rosso)	enclosure upper part (red part) bovenkant behuizing (rode deel)	1
33	892142545.21	INP-21-DISPLAY LCD-Anzeige affichage LCD LCD display	LCD display LCD display	1
34	892142544.2	IN-21-B6 Indikatorplatine carte indicateur scheda indicatore	indicator print board indicator board	1
35	892207350	HOP-MC Zwischendeckel plaque fixation carte indicateur copertura scheda indicatore	middle cover tussen deksel	1
36	893203006	HOP-BLO-ENC-LOW Stosskissen Gummi caoutchouc anti vibration gomma di protezione adesiva	rubber pad rubberen stootkussen	2
37	893131220	BA-1,5-PENN-AA-R6 AA Batterie 1,5 Volt Batterie AA 1,5 Volt Batteria AA 1,5 Volt	AA battery, 1,5 Volt AA batterij, 1,5 Volt	4
38	893151358	BAP-SNAP-SINGLE Batteriekontakte einzel lamelle contacts simples clip di contatto batteria singola	battery contact clips single batterij-contactclips single	2
39	893151358.1	BAP-SNAP-DUAL Batteriekontakte doppel lamelle contact double clip di contatto batteria doppia	battery contact clips dual batterij-contactclips dual	1
40	893153000	HOP-RAV-STRAINRELIEF Zugentlastungskabel câble de maintien boîtier filo antiribaltante	strain relief cable trekontastingskabel	2
41	893141175	HOP-RAV-RAL9011-LOWER Unterer Teil Gehäuse partie inférieure du boîtier parte inferiore custodia	enclosure lower part onderkant behuizing	1
42	898141171.3	SA-IN-21-B-6V-RAV-RAL3000 Indikator komplett indicateur complet indicatore completo	indicator complete indicator compleet	1

